

Item: **6516** - Plastic digital kitchen timer

POSITION:

1. FRONT
2. BELOW THE BUTTONS

AREA:

35mm x 10mm
45mm x 15mm

METHOD:

PAD
DIGITAL

